




CÓDIGO	Ø INTERNO DA MANGUEIRA (T1)	ROSCA BSP (T2)
	POL MM	POL
BMF-2B-316	1/8 3,17	1/8
BMF-3.2B-316	3/16 4,76	1/8
BMF-4.6B-316	1/4 6,35	3/8
BMF-4.8B-316		1/2
BMF-5.6B-316	5/16 7,93	3/8
BMF-5.8B-316		1/2
BMF-6.4B-316	3/8 9,53	1/4
BMF-6B-316		3/8
BMF-6.8B-316		1/2
BMF-8.6B-316	1/2 12,70	3/8
BMF-8B-316		1/2
BMF-8.12B-316		3/4
BMF-12.8B-316	3/4 19,05	1/2
BMF-12B-316		3/4