




CÓDIGO	ROSCA NPT (T1)	ROSCA NPT (T2)	DIMENSÃO (A)	DIMENSÃO (B)	CHAVE (D)
	POL	POL	MM	MM	POL
BRMF-4.2-316	1/4	1/8	20,2	14,2	9/16
BRMF-6.2-316	3/8	1/8	20,2	14,2	11/16
BRMF-6.4-316		1/4	20,2	14,2	11/16
BRMF-8.2-316	1/2	1/8	27	19	7/8
BRMF-8.4-316		1/4	27	19	7/8
BRMF-8.6-316		3/8	27	19	7/8
BRMF-12.2-316	3/4	1/8	27	19	1.1/16
BRMF-12.4-316		1/4	27	19	1.1/16
BRMF-12.6-316		3/8	27	19	1.1/16
BRMF-12.8-316		1/2	27	19	1.1/16
BRMF-16.4-316	1	1/4	35	24	1.3/8
BRMF-16.6-316		3/8	35	24	1.3/8
BRMF-16.8-316		1/2	35	24	1.3/8
BRMF-16.12-316		3/4	35	24	1.3/8